



PO Box 340, Concord, CA 94523 USA (925) 798-BEVL [2385]  
<Steve@BevelHeaven.com> <http://www.BevelHeaven.com>

## Dr Desmo Bar Riser Kit Instructions — ST2, ST4 & ST4s < 1/2" 3/4" and 1" rise >

-> Dr Desmo risers work with all ST2, ST4, ST4s from 1997-2003 that have the bolt-on clip-ons

If black rubber hoses are present, nothing else is needed, however if the clear stainless-steel lines are there, a pair of my stainless steel hose extenders are need to avoid straining the lines (or new -longer lines must be purchased; Monster S4 work)

(some 2003 bikes have the later style clip-ons that bolt to the fork tubes (NOT the triple clamp), and are individually height adjustable, these will not work with the risers!!!

### Install info:

torque specs are: grease/oil threads (Blue #242 Loctite optional) at 17 ft/lbs. / 2.4 Kgm / 23.55 Nm.

on bikes with remote clutch and brake reservoirs, a slight bending of the mounting may be required to clear the fairing

the fork stop bolts under the lower triple clamp can be adjusted to address clearance issues...

the choke cable on the LH side should be unhooked from the wire bail to obtain extra length

\* IMPORTANT: before riding, check that the engine does not race at either full lock position! This can be done most safely on the center stand while in neutral

### For OEM stock bar position:

1. remove stock bolts
2. install inside bolts from above and finger tighten
3. install outside bolts from below and torque
4. torque inner bolts

### For 7.5 degree swept-back position:

1. remove stock bolts
2. install inner bolts from above and finger tighten
3. install M8x25 bolts from below into the riser & torque
4. install outer bolts from below and torque
5. torque inner bolts

